

OVERVIEW

**ART. 3021**

3000 Smart Series "4+1" audiophone incorporating an AC buzzer call and "door open" push button.

For use on traditional "4+1" audio and video systems that require an AC buzzer call.



**3021**  
**Smart Series Audiophone**  
**QUICK GUIDE**




**TECHNICAL SUPPORT**  
 Tel: 0191 224 3174  
 Fax: 0191 224 4938  
 Email: tech@videxuk.com  
 Web: www.videxuk.com

06\_3021\_V1.0\_08/17



## ANSWERING A CALL

buzz!  
buzz!




During a call

1



To answer an incoming call pick up the handset.

2




With the handset lifted a conversation with the caller can begin.

3




To end the call replace the handset back on the cradle.


## TO OPEN THE DOOR



During a conversation

1



With the handset lifted, press the lock button  to operate the lock.

2



To end the call replace the handset back on the cradle.

## TECHNICAL ADVICE

For further technical advice and assistance on the installation of this product please contact Videx technical on tel: 0191 224 3174.

For any sales advice and assistance please contact Videx sales on tel: 0191 238 8324.

To download a copy of this quick guide visit the Videx website: [www.videxuk.com](http://www.videxuk.com)

