

1. Remove plastic coverstrips. fold RP62 so aluminium meets together (**FIG 1**) ensuring desired colour is facing outwards, if not remove PVC barrier, rotate and replace into aluminium. Clamp RP62 and machine cut the aluminium and the PVC to size. Neatly biff or centre punch back side of aluminium to lock in PVC barrier preventing movement.

2. With door fully open, position one side of RP62 on door face. Check to make sure other side of RP62 will reach door jamb or stop. Lightly screwfix in centre of every slot (**FIG 3**).

3. Position other side of RP62 on door stop or jamb. Lightly screwfix in centre of every slot. (**FIG 3**).

4. Open and shut the door to check for correct latching. Adjust RP62 if needed. Tighten all fixing screws.

5. Measure and cut coverstrip to size. Push in the cover strip. Neatly biff or centre punch each end of aluminium to lock in coverstrip preventing movement.




FIG 1



FIG 2





FIG 3



Part No. ZSDSRP62BW
© COPYRIGHT 07/10